



<b>Property of</b>		<b>TITLE</b>	
<b>QUICK CABLE</b>		<b>Switch to starter cable, 6ga</b>	
3700 Quick Dr. Frankeville WI		<b>PART #</b>	
		<b>740161</b>	
<b>Material &amp; Treatment</b>		<b>Drawing #</b>	<b>REV</b>
		<b>740161-Info</b>	<b>A</b>
		<b>Sheet 1</b>	<b>of 1</b>

		<b>Drawn By</b>	<b>Date</b>	<b>Checked By</b>	<b>Scale</b>
		<b>Paul</b>	<b>7/8/03</b>	<b>ME</b>	<b>None</b>
<b>Tolerances, unless otherwise noted</b>					
<b>A</b>	<b>7/8/03</b>	<b>Paul</b>	<b>Redrawn replaces dwg#10730</b>		
<b>Rev</b>	<b>Date</b>	<b>By</b>	<b>Description</b>		