



## Operating Instructions

1. Disconnect blue voltage selector plug on front.
2. Turn off all non-essential electrical accessories on vehicle to be started.
3. Connect red battery clamp to positive battery post, and black clamp to vehicle ground away from the battery.
4. Determine voltage of vehicle to be started. Connect blue voltage selector plug to either 12-V or 24-V plug as required.
5. Start vehicle and disconnect blue voltage selector plug and battery clamps.
6. Keep battery charger plugged in to maintain unit when not in use.


[quickcable.com](http://quickcable.com) | [quickhowto.com](http://quickhowto.com)



**12-V**



**Voltage Selector**



**24-V**

9" x 4"